




# GAMMES TRANSFORMATEURS DE COURANT

## SERIE MINI

TYPE	TAM 1D	TAM 3D	TAM 4D	TAM 5D	TAM 6
APPLICATION	Passage primaire				
 HORIZ. BAR  CABLE		20 x 12 25 x 15 30 x 10	25 x 25 30 x 20 40 x 10	50 x 12	50x23 63x20
	21	23	30		2 x 22
 VERT. BAR			25 x 25 30 x 20 40 x 10		
Courant primaire (A)	Charge (VA)	Charge (VA)	Charge (VA)	Charge (VA)	Charge (VA)
	Classe	Classe	Classe	Classe	Classe
	0,5   1   3	0,5   1	0,5   1	0,5   1	0,5   1
<b>40</b>	1,3				
<b>50</b>	1,5				
<b>60</b>	1,5				
<b>75</b>	1,5				
<b>80</b>	2				
<b>100</b>	3	1,5	3		
<b>120</b>	3	1,5	3		
<b>125</b>	3	1,5	3		
<b>150</b>	4	3	3		
<b>200</b>	3	3	4		
<b>250</b>	3	2	6	3	
<b>300</b>		2	6	4	5
<b>400</b>		3	10	4	6
<b>500</b>			10	6	6
<b>600</b>			10	6	6
<b>800</b>				10	10
<b>1000</b>				10	10
<b>1200</b>					15
<b>1250</b>					15
<b>1500</b>					20
<b>2000</b>					20
<b>2500</b>					
<b>3000</b>					
<b>4000</b>					
<b>5000</b>					
<b>6000</b>					
hauteur	65	65	81,5	81,5	106
largeur	52	52	70	70	101
prof.	27	27	44	44	44
entraxes min.					
VOIR PAGE	260	260	261	261	262



# GAMMES TRANSFORMATEURS DE COURANT

## SERIE STANDARD

## SERIE STANDARD - CLASSES SPECIALES

TYPE	TAR PDE1	TAR PDE2	TAR PD1	TAR PD2	TAR 0	TAR 1D	TAR 3D	TAR 4D	TAR 4D3	TAR 5	TAR 6	TAR 8	TAR 12	TAR 8V	TAR 12V
	Charge (VA) Classe	Charge (VA) Classe	Charge (VA) Classe	Charge (VA) Classe	Charge (VA) Classe	Charge (VA) Classe	Charge (VA) Classe	Charge (VA) Classe	Charge (VA) Classe	Charge (VA) Classe	Charge (VA) Classe	Charge (VA) Classe	Charge (VA) Classe	Charge (VA) Classe	Charge (VA) Classe
APPLICATION HORIZ. BAR	15 x 3 torque	25 x 3 torque	25 x 5 torque	25 x 3 torque	20 x 3	20	20 x 10 30 x 10	30 x 30 40 x 25 - 50 x 20	30 x 10	50 x 20 60 x 20	50 x 20 60 x 20	60 x 30 80 x 30	80 x 50 100 x 50 125 x 50		
	Passage primaire														
APPLICATION CABLE					15	20	21	32	25	30	50	2 x 30	2 x 50	2 x 35	3 x 35
	Passage primaire														
APPLICATION VERT. BAR							20 x 10 30 x 20 40 x 10	30 x 10	30 x 10	30 x 10	30 x 10	30 x 10	30 x 10	30 x 10	30 x 10
	Passage primaire														
SECTION CENTRALE							20 x 10 30 x 20 40 x 10	30 x 10	30 x 10	30 x 10	30 x 10	30 x 10	30 x 10	30 x 10	30 x 10
	Passage primaire														
Courant primaire (A)							20 x 10 30 x 20 40 x 10	30 x 10	30 x 10	30 x 10	30 x 10	30 x 10	30 x 10	30 x 10	30 x 10
	Passage primaire														
1	3	6	6	6	0,5	1	3	0,5	1	3	0,5	1	3	0,5	1
5	3	6	6	6	2	2	2	2	2	2	2	2	2	2	2
10	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
15	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
20	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
25	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
30	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
40	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
50	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
60	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
80	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
100	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
125	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
150	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
200	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
250	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
300	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
400	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
500	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
600	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
750	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
800	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
1000	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
1200	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
1500	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
1600	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
2000	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
2500	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
3000	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
4000	3	6	6	6	3	3	3	3	3	3	3	3	3	3	3
DIMENSIONS	hauteur	75	75	75	67	75	87	87	100	110	120	175	119	165	
	largeur	58	58	58	55	58	58	75	75	85	105	125	180	109	
VOIR PAGE	prof.	44	44	44	35	44	44	44	45	61	61,5	68,5	41	41	
		272	272	272	273	273	274	275	274	275	276	276	277	277	278